



INSTALLATION OVERVIEW. ON CONCRETE FLOOR




STEP 1
Connect easy-clean trap body to outlet pipe. Install other required plumbing.



STEP 2
Adhere Vivo tray to floor with approved tile adhesive. Allow 24 hours curing before walking on tray.



STEP 3
Install pro NICHE if being utilised. Cut wet-area wallboard to suit and affix to framing.



STEP 4
Apply waterproofing membrane to shower walls, shower tray, and bathroom floor.



STEP 5
Apply tile to shower tray, walls, and bathroom. Adhere glazing channel to tiled tray and walls.



STEP 6
Install plumbing fixtures to shower. Install frameless-glass enclosure.