



INSTALLATION OVERVIEW. PLYWOOD ON-FLOOR



STEP 1

Connect easy-clean trap body to outlet pipe. Install other required plumbing.



STEP 2

Adhere Vivo tray to rebated floor with approved tile adhesive. Allow 24 hours curing before walking on tray.



STEP 3

Install pro NICHE if being utilised. Cut wet-area wallboard to suit and affix to framing.



STEP 4

Apply waterproofing membrane to shower walls, shower tray, and bathroom floor



STEP 5

Apply tile to shower tray, walls, and bathroom. Adhere glazing channel to tiled tray and walls.



STEP 6

Install plumbing fixtures to shower. Install frameless-glass enclosure.